AUTOTECNICA IMPORTS PTY LTD
48 NORTHGATE DRIVE
THOMASTOWN 3074
VICTORIA AUSTRALIA
WWW.AUTOTECNICA.COM.AU
TELEPHONE (03) 9464 2200
FACSIMILE (03) 9464 1400
A.C.N. 004 230 63
ABN 24 847 451 725







EXCLUSIVE **A**UTOMOTIVE **P**RODUCTS

SEAT FITTING INSTRUCTION AUTOTECNICA SEATS REPLACEMENT SEAT ADAPTOR / PART NO: 644 (L&R) NISSAN S13-S14-S15

PLEASE READ THE INSTRUCTION IN FULL BEFORE FITTING AUTOTECNICA SEATS TO THE VEHICLE.

- 1. Park the vehicle and ensure the hand brake is on.
- 2. Remove the seat from the vehicle and retain the bolts removed to be used when refitting the new seat. If the seat has a seat belt attached please remove the seat belt from the seat to be attached to the provided anchorage point onto the new adaptor with the provided bolt.
- 3. Place the new Autotecnica seat upside down in a suitable position and place the 4 supplied washes on the seat mounting holes. "Photo (A)"

Photo (A)



Contents

- 4 X 3MMX22MM WASHERS
- 4 X 30MM M8 BOLTS (1xspare)
- 1 x 25MM M8 flat head bolt right hand only
- 4 X SPRING/FLAT WASHERS
- 1 X SEAT BELT NUT/BOLT
- 4. Insert the "U" shaped handle onto the locating pins of the adaptor if not attached to the slider. *Please wedge in a flathead screwdriver when fitting the "U" shaped handle onto the pins. See "photo 'B". Place the assembled adaptor onto the seat ensuring the seat holes line up to the adaptor mounting holes.
- 5 Starting from the back of the seat use the supplied bolts and washers to attach the adaptor/slider onto the seat. Secure the bolts but do not tighten them.
 - Using the adjusting lever "U shape front of seat" move the seat frontwards to locate the other two mounting holes. Place and secure the bolts to the other two mounting holes. Note: the flat head bolt supplied is used on the narrow space at the front of the adaptor.

Secure all bolts to correct tension



*For an easier fitment, wedge in a flat head screw driver between the track and handle to slide and possition the "U shape" handle over the locating pins



Photo (C)

5. Place the assembled seat onto the original seat mounting holes by using the 4 original bolts and washers. In some vehicles, larger washes are needed. Washes not supplied. Secure all bolts to correct tension. Photo "C" Attach the removed seat lap belt to the bracket of the adaptor with the provided bolt and nut/washers and secure it correctly.



All Images used for illustration purposes only

Note: The Autotecnica seats and the 639F adjusters (sliders) are ADR approved.

