

AUTOTECNICA IMPORTS PTY LTD  
48 NORTHGATE DRIVE  
THOMASTOWN 3074  
VICTORIA AUSTRALIA  
WWW.AUTOTECNICA.COM.AU  
TELEPHONE (03) 9464 2200  
FACSIMILE (03) 9464 1400  
A.C.N. 004 230 63  
ABN 24 847 451 725



EXCLUSIVE DISTRIBUTORS OF:

**MONZA**

**ADVENTURER**

EXCLUSIVE AUTOMOTIVE PRODUCTS

**SEAT FITTING INSTRUCTION AUTOTECNICA SEATS  
REPLACEMENT SEAT ADAPTOR / PART NO:662NISL-662NISL (L&R)NISSAN D40  
NOTE: RIGHT AND LEFT ASSEMBLY IS THE SAME**

**PLEASE READ THE INSTRUCTIONS IN FULL BEFORE FITTING AUTOTECNICA SEATS TO THE VEHICLE.**

**NOTE: ADAPTORS NOT SUITABLE FOR VEHICLE WITH AIR BAGS IN THE SEATS**

**ASSEMBLY PARTS**

- 2 X Front & Rear Floor Attachment Adaptor Bars
- 2 X Left & Right Adjustments Sliders With seat belts anchorage attachments
- 2 X Connecting Bars
- 20X Washers Flat And Spring Washes
- 8X 25MM M8 Bolt
- 4 X 35MM M8 Bolts
- 1 X 10MM seat bolt washers+Nuts
- 4 X 15MM Spacers

Front&rear floor  
Attachments

Left&right sliders

Connecting bars



Bolts/nuts/washers/spacers

**Adaptor Floor Connecting bars assembly**

Connect the front and the rear floor adaptor bars to the two connecting bars using the 4X25MM bolts with the provided nuts and washers. **Photo"A"**

**Do not secure at this stage.**

Place the assembled **Photo"A"** onto the vehicle floor seat mounting holes and adjust the assembly to match to the corresponding floor holes.

Take some time in positioning the floor adaptor bars correctly as the correct position will also line up the tabs of the sliders to accept the adjusting U shape bar. **Photo"C"**

Once the adaptors is correctly lined up with the floor seat mouting holes, secure all the bolts of the adaptor bars, whilst on the vehicle floor.

**DO NOT BOLT THE ADAPTOR TO THE FLOOR AT THIS STAGE.**



**Photo"A"**



**2x Connecting Bars**

**Assembled floor adaptors attached to connecting bars**

## ATTACHING THE ADAPTOR PLATE TO THE SEAT

Place the two sliders **Photo"B"** onto the assembled unit **Photo "A"**. Ensure the sliders are fitted to the assembled adaptor as per the **Photo"C"**. Note the seat belt anchorage point where the seat belt will attach with the provided 10MM bolt/nut/washers. This adaptor suit the R/H of the vehicle.

Use the 4x25mm bolts and nuts to attach the sliders **Photo"B"** onto the Adaptor assembly. Note upright seat belts anchorage. To gain sufficient room under the slider so that the bolt can be secured, move the slider forward backwards by pushing the U shape handle down. **Photo"C"**  
The adaptor is now ready to be attached to the new seat.



**Photo"B"** Sliders bars positioning



**Photo"C"** Front of adaptor with U Shape Handle

### ADAPTOR ASSEMBLY COMPLETED.

**The** completed adaptor assembly **Photo"C"** is now ready to be fitted onto the seat. Place the seat in an upside down position and insure the 4x15mm spacers are inserted onto the seat base mounting holes. See **Photo"D"**.

Some Autotecnica seats do not need the 15mm spacers. In this case they should be used. The M8x35mm bolts and washers supplied are to attach the adaptor onto the seat. Use the original seat mounting bolts to secure the seat in to the vehicle floor.



*The image used above is for purposes only*

**Photo"D"**



**8X15MM SPACERS POSITION**

**Note: The Autotecnica seats and the 639F adjusters (sliders) supplied are ADR approved**  
**We recommend however that the seat conversion is checked by an accredited engineer after fitting the seat or seats to the vehicle.**